

NOTES:

- 1. DETAIL SHOWS **HENRY 790-11/790-11EV** HOT RUBBERIZED ASPHALT WATERPROOFING ASSEMBLY TRANSITION WITH HENRY **PUMADEQ SYSTEM**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- RECOMMENDED HENRY ADHESIVE/PRIMER FOR HENRY 790-11/790-11EV INCLUDE: HENRY 910-01 ASPHALT PRIMER
 OR HENRY 930-18 POLYMER MODIFIED ADHESIVE. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET TO
 CONFIRM VOC COMPLIANCE.
- TRANSITION DETAIL IS SUITABLE FOR BOTH REINFORCED AND UNREINFORCED PUMADEQ SYSTEM FIELD
 MEMBRANE APPLICATIONS. TOP, WEAR, AND TRAFFIC COATING NOT SHOWN FOR CLARITY. REFER TO PUMADEQ
 SYSTEM DETAILS FOR FURTHER CLARITY.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY **PUMADEQ** SYSTEM SUBSTRATE PREPARATION GUIDELINES.
- HENRY OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS. CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 6. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



El Segundo, CA 90245

800-486-1278 • www.henry.com

HENRY 790-11/790-11EV AND PUMADEQ SYSTEM TIE IN

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRI 190-11/190-11EV AND FOMADEQ 3131EM HE II

TIE-IN DETAIL

DISSIMILAR MATERIAL TRANSITIONS HENRY 790-11/790-11EV AND PUMADEQ SYSTEM ____

07-08-2019

SCALE: N.T.S.

790-11-TID-3A1