



Notes:

1. When Blueskin membranes are used for the air-vapor barrier, the brick tie system can be installed after the Blueskin is installed. This helps assure continuity and significantly reduces installation time.
2. Air-Bloc 21 may be used as an adhesive to bond rigid insulation to Blueskin SA. Air-Bloc 21 is applied by notched trowel or gunned in a serpentine pattern to the back of the insulation panels to restrict air movement. Insulation panel joints are also buttered.
3. The transition membrane from the wall to the roof assembly should tie-in to the roof air/vapor barrier to ensure air seal continuity. Ensure compatibility.

Henry
COMPANY®

BLUESKIN SA

SCALE: N.T.S.

BRICK VENEER/ STEEL STUD WALL

FIT TO PAPER

**PARAPET
DETAIL**

AB-H103