



Notes:

1. Blueskin TWF is a self-adhering sheet used for thru-wall flashing applications. Blueskin TWF is to be applied to a prepared and primed substrate.
2. Always stop Blueskin TWF flashing membrane back from exterior face of veneer. Extend the drip edge using prepainted metal to suit.
3. Air-Bloc 21 may be used as an adhesive to bond rigid insulation to exterior sheathing or other Air-Bloc systems. Air-Bloc 21 is applied by notched trowel or gunned in a serpentine pattern to the back of the insulation panels to restrict air movement. Insulation panel joints are also buttered.
4. When the brick tie system is installed prior to the Blueskin, the membrane is cut, fitted and sealed with Air-Bloc 21 around each tie projection. A 2' lap is needed over the ties.

Henry
COMPANY

BLUESKIN SA

BRICK VENEER/ CMU WALL

**SHELF ANGLE
DETAIL**

SCALE: N.T.S.

FIT TO PAPER

AB-H108