



Notes:

1. Blueskin TWF self-adhering sheets are used for thru-wall flashing applications. Blueskin TWF is applied to a prepared and primed substrate.
2. Integrate the wall air/vapor barrier system with foundation waterproofing and dampproofing system.
3. When the brick-tie system is installed prior to the Blueskin membrane, cut and fit the membrane around each tie and seal with Air-Bloc 21.
4. An alternate detail for the thru-wall flashings includes extending the membrane across the top of the floor slab prior to installing the lower track.

	BLUESKIN SA	SCALE: N.T.S.
	BRICK VENEER/ STEEL STUD WALL	FIT TO PAPER
FOUNDATION DETAIL	AB-H110	