



Notes:

1. Refer to Henry Air-Bloc® 33MR Guide Specifications and Technical Data Sheets for recommended installation procedures and requirements.
2. Surfaces to receive Henry transition membrane must be properly prepared and primed according to Henry documents.
3. Treat inside and outside corners with Henry transition membrane extending a minimum of 3 inches on either side of the corner detail.
4. Roll Henry transition membrane with counter top roller after application.



VAPOR PERMEABLE AIR-BLOC 33MR MEMBRANE

SCALE: N.T.S.

EXTERIOR SHEATHING

09-30-13

**CORNER
DETAILS**

AB-H129