

BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435

BLUESKIN PRESEAL TAPE 120V

BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435 (SET MEMBRANE INTO A BED OF WET **HENRY 925 BES SEALANT)**

FASTENER

HENRY 925 BES SEALANT SET EXPANSION JOINT INTO A BED OF WET HENRY 925 BES SEALANT

HENRY 925 BES SEALANT

GAPS GREATER THAN 2" (50MM) WIDE (REFER TO EXPANSION JOINT MANUFACTURER REQUIREMENTS)

BLUESKIN PRESEAL TAPE 120V

HENRY 925 BES SEALANT

FASTENER AND TERMINATION BAR

HENRY 925 BES SEALANT

SOIL RETENTION SYSTEM (DO NOT INSTALL BLUESKIN PRESEAL 320 DIRECTLY ONTO SHEET PILING - PREPARE SUBSTRATE WITH A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD)

HENRY DRAINAGE COMPOSITE

PLAN VIEW

VERTICAL WALL TO VERTICAL WALL

NOTES:

- DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR APPLICATIONS USING HENRY BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
- HENRY BLUESKIN PRESEAL 435 CAN BE INSTALLED DIRECTLY ONTO SHEET PILING. BLUESKIN PRESEAL 320 REQUIRES A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD.
- HENRY RECOMMENDS THE USE OF A DRAINBOARD IN NON-HYDROSTATIC CONDITIONS, OR AS A SUBSTRATE PREPARATION.
- REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET (TDS) AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION

HENRY PRE-APPLIED WATERPROOFING SYSTEM

EXPANSION JOINT

VERTICAL WALL TO VERTICAL WALL **GAPS GREATER THAN 2" (50MM) WIDE** SCALE: N.T.S.

09-14-2022

BSPS-11A2B