



**NOTES:**

1. DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR APPLICATIONS USING HENRY **BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
2. FASTEN PRE-APPLIED WATERPROOFING ONTO GRADE BEAM/FOOTING AS REQUIRED. SEAL FASTENERS WITH **HENRY 925 BES SEALANT** PRIOR TO **BLUESKIN PRESEAL TAPE 120V** INSTALLATION.
3. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

**HENRY PRE-APPLIED WATERPROOFING SYSTEM**

**GRADE BEAM/FOOTING**

**BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435**  
**STEEL COLUMN ON SLAB**

SCALE: N.T.S.

11-06-2023

**BSPS-4B.3**

