



NOTES:

1. INSTALL PLYWOOD OR CCW MIRADRAIN COMPOSITE TO FORM A FLAT SURFACE. FASTEN CCW-MIRACLAY TO FLAT SURFACE.
2. AT BASE OF WALL INSTALL ONE ROW OF CCW-MIRACLAY HORIZONTAL TO MINIMIZE SPLICES.
3. FASTEN CCW-MIRACLAY AT THE SEAMS, TO ALLOW IT TO CONFORM TO THE SUBSTRATE. MAX. FASTENER SPACING IS 12" O.C.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

C-5C

SHEET PILING



© 2014 CARLISLE CORPORATION