



- NOTES:
1. FORM CCW-MIRACLAY TO THE SHEET PILING WITH MECHANICAL FASTENERS.
 2. TERMINATE CCW-MIRACLAY USING CCW TERMINATION BAR FASTENED A MAX. OF 12" O.C. WITHIN 2" OF TOP EDGE OF CCW-MIRACLAY.
 3. APPLY 3/4" LAYER OF CCW-MIRACLAY SEALANT EXTENDING AT LEAST 4" ONTO THE CCW-MIRACLAY.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

C-9A

SHEET PILING TERMINATION

