



Note:

1. Treat non-moving joints with an additional ply of polyester reinforcement set into wet CM100 membrane.
2. Extend polyester reinforcement minimum 3 inches over vertical and horizontal surfaces.
3. Protection course required over completed membrane application.

Henry
COMPANY®
www.henry.com

CM100 WATERPROOFING - HIGH BUILD SYSTEM

SCALE: N.T.S.

CONCRETE DECK

05-05-09

**CURB
DETAIL**

CM-HB03