



Notes:

1. Set elastomeric flashing sheet in a bed of wet CM100 and allow to cure.
2. Coat elastomeric flashing sheet with CM100 and set polyester reinforcement into wet CM100 and allow to cure.
3. Coat polyester reinforcement with CM100 and install protection course (not shown).
4. Allow CM100 membrane to fully cure prior to placement of additional coats.
5. Extend polyester reinforcement minimum 3 inches over vertical and horizontal surfaces.
6. Protection course required over completed membrane application.