



**Polyester Fabric  
Joint Treatment**

**Elastomeric Flashing  
Joint Treatment**

**Notes**

1. Polyester reinforcement or elastomeric flashing sheet to extend min. 4" beyond change of plane
2. Set polyester reinforcement or elastomeric flashing sheet in a bed of wet CM100 and allow to cure.
3. Coat polyester reinforcement with CM100 and allow to cure.



CM100 WATERPROOFING - SINGLE COAT SYSTEM

SCALE: N.T.S.

TYPICAL DETAIL

05-05-09

**FOUNDATION  
WALL**

**CM-SC01**