



Polyester Fabric Joint Treatment

Elastomeric Flashing Joint Treatment

Notes

1. Polyester reinforcement or elastomeric flashing sheet to extend min. 4" beyond change of plane
2. Set polyester reinforcement or elastomeric flashing sheet in a bed of wet CM100 and allow to cure.
3. Coat polyester reinforcement with CM100 and allow to cure.

Henry
COMPANY®

CM100 WATERPROOFING - SINGLE COAT SYSTEM

SCALE: N.T.S.

TYPICAL DETAIL

05-05-09

FOUNDATION
WALL

CM-SC01