



Notes:

1. The modifiedPLUS flashing membranes are thermofused to the primed substrate. The granulated cap sheet can be left exposed.
2. Alternatively, use modifiedPLUS NP180 Tack Sheet, a self-adhered base sheet flashing, and thermofuse the granulated cap sheet flashing over.
3. Prime with 930-18 or 910-01 when using thermofusible membrane. For self-adhered modifiedPLUS NP180 Tack Sheet use 930-18 primer.

Henry
COMPANY

790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

CONCRETE DECK - PARAPET

FIT TO PAPER

**2-P THERMOFUSED
FLASHING DETAIL**

HR-H108