



Notes:

1. An air/vapor barrier transition membrane, such as Blueskin, is installed prior to the wood parapet. This ties the 790-11 system into the wall air/vapor barrier to maintain continuity.
2. Alternatively, the joints in the gypsum board roof deck may also be treated with 4" BlueskinSA or Neoflash w/ adhesive, prior to applying the 790-11 membrane system.



790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

STEEL DECK / PLYWOOD PARAPET

FIT TO PAPER

**SBS
FLASHING DETAIL**

HR-H110