


Notes:

1. An air/vapor barrier transition membrane, such as Blueskin, is installed prior to the wood parapet. This ties the 790-11 system into the wall air/vapor barrier to maintain continuity.
2. Alternatively, the joints in the gypsum board roof deck may also be treated with 4" BlueskinSA or Neoflash w/ adhesive, prior to applying the 790-11 membrane system.

	790-11 MEMBRANE P.M.R. ASSEMBLY	SCALE: N.T.S.
	STEEL DECK / PLYWOOD PARAPET	FIT TO PAPER
SBS FLASHING DETAIL	HR-H110	