



**Notes:**

1. The flashing sheet can be either Neoflash or modifiedPLUS NP180 s/s.
2. Follow appropriate codes for minimum vent height above roof deck.
3. Keep the flashing sheet  $\frac{1}{2}$ " back from the vent stack and carry the 790-11 membrane up to the stack to ensure a complete seal.



790-11 MEMBRANE P.M.R. ASSEMBLY

SCALE: N.T.S.

CONCRETE DECK - PENETRATION

FIT TO PAPER

**VENT/PROJECTION  
DETAIL**

**HR-H120**