



NOTES:

1. Extend BarriCOAT a minimum of $\frac{1}{2}$ " beyond MiraPLY Seam Tape.
2. CCW-MiraDRAIN HC or CCW approved perimeter drain not shown for clarity.
3. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

MiraPLY™ BLINDSIDE WATERPROOFING

MIRAPLY-H TO BARRICOAT
AT FOOTING TIE-IN



© 2020 CARLISLE CORPORATION

02/24/2020

N.T.S.

MP-100