



**NOTES:**

1. Protect the MiraWELD from damage during removal of Retention Wall System and work by other Trades.
2. MiraDRAIN or CCW approved protection course is required prior to backfill placement.
3. Concrete deck should be sloped to drain as per Specification.
4. Install MiraDRI on concrete deck in a water-shedding fashion.
5. Separate Wearing Course (Deck Overburden) not shown for clarity.
6. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

02.24.2021 | N.T.S.

**MW-115**

**MiraWELD™** BLINDSIDE WATERPROOFING

MIRAWELD™ - MIRADRI™ 860/861  
WALL TO DECK TIE-IN



© 2021 CARLISLE CORPORATION