



**NOTES:**

1. Extend the MiraWELD a minimum of 12" above the concrete pour and protect from damage.
2. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

02.24.2021 | N.T.S.

**MW-142B**

**MiraWELD™** BLINDSIDE WATERPROOFING

MIRAWELD™ - MIRACLAY™  
BLINDSIDE WALL TIE-IN



© 2021 CARLISLE CORPORATION