



NOTES:

1. Protect the MiraWELD from damage during removal of Retention Wall System and work by other Trades.
2. MiraDRAIN or CCW approved protection course is required prior to backfill placement.
3. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

02.24.2021 | N.T.S.

MW-142D

MiraWELD™ BLINDSIDE WATERPROOFING

MIRAWELD™ - MIRACLAY™
WALL TIE-IN



© 2021 CARLISLE CORPORATION