



**NOTES:**

1. Protect the MiraWELD from damage during removal of Retention Wall System and work by other Trades.
2. MiraDRAIN or CCW approved protection course is required prior to backfill placement.
3. When required, ensure the sealant fully encapsulates the term bar.
4. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

**MiraWELD™** BLINDSIDE WATERPROOFING

02.24.2021 | N.T.S.

**MW-70**

TERMINATION AT FINISHED GRADE



© 2021 CARLISLE CORPORATION