



NOTES:

1. Use CCW approved fasteners to secure the MiraWELD Detail Strip towards the outer edge of the TPO selvedge as necessary.
2. Install MiraWELD-H & MiraWELD-V to MiraWELD Detail Strip with a minimum 1-1/2" continuous hot-air weld.
3. Ensure the membrane lays flat and no openings are visible.
4. All hot-air welded seams must be probed for integrity.
5. Apply MiraPLY Detail Tape centered over all welded seams and roll with a 2" silicone roller.
6. MiraWELD Detail Strip may also be used at other transitions/changes in plane (e.g. vertical inside corner).
7. Refer to Technical Data Sheets for additional information.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

02.24.2021 | N.T.S.

MW-82

MiraWELD™ BLINDSIDE WATERPROOFING

MIRAWELD DETAIL STRIP



© 2021 CARLISLE CORPORATION