

## NOTES:

- DETAIL SHOWS HENRY BLUESKIN WP200 SELF-ADHERED WATERPROOFING TRANSITION WITH HENRY PUMADEQ SYSTEM. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. REFER TO THE BLUESKIN WP200 TECHNICAL DATA SHEET FOR PRIMER RECOMMENDATIONS.
- TRANSITION DETAIL IS SUITABLE FOR BOTH REINFORCED AND UNREINFORCED PUMADEQ SYSTEM FIELD
  MEMBRANE APPLICATIONS. TOP, WEAR, AND TRAFFIC COATING NOT SHOWN FOR CLARITY. REFER TO PUMADEQ
  SYSTEM DETAILS FOR FURTHER CLARITY.
- PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND PUMADEQ SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PUMADEQ SYSTEM SUBSTRATE PREPARATION GUIDELINES.
- HENRY OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS. CONTACT HENRY FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 6. REFER TO PRODUCT SPECIFIC GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



PUMADEQ SYSTEM TIE-IN TO BLUESKIN WP200

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

## POMADEQ 3131EM HE-IN TO BLUESKIN WF200

TIE-IN DETAIL

DISSIMILAR MATERIAL TRANSITIONS
PUMADEQ SYSTEM AND BLUESKIN WP200

SCALE: N.T.S.

07-08-2019

PMDQ-TID-A3B

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com