

NOTES:

- DETAIL SHOWS HENRY[®] PUMADEQ[™] SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ[™]** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY[®] **PUMADEQ[™]** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 3. DO NOT INSTALL **PUMADEQTM** SYSTEM BEYOND PRIMED SURFACES.
- 4. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ[™]** RESIN.
- 5. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 6. REFER TO **PUMADEQTM** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



DUMA DEOTM OVOTEM WATERBROOFING ACCEMBLY

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY 8 DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQ[™] SYSTEM - WATERPROOFING ASSEMBLY

CURB FLASHING

REINFORCED FIELD MEMBRANE UPTURN FLASHING AT CURB WITH TOP OR WEAR COAT

SCALE: N.T.S.

04-26-2019

PUMADEQ-C3D

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com