

## NOTES:

- DETAIL SHOWS HENRY<sup>®</sup> **PUMADEQ<sup>™</sup>** SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ**<sup>TM</sup> SYSTEM APPLICATION IN ACCORDANCE WITH HENRY<sup>®</sup> **PUMADEQ**<sup>TM</sup> SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- DO NOT INSTALL **PUMADEQ<sup>TM</sup>** SYSTEM BEYOND PRIMED SURFACES. 3.
- BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ™** RESIN.
- HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- REFER TO **PUMADEQ<sup>™</sup> SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.**



DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR

## PUMADEQ<sup>™</sup> SYSTEM - WATERPROOFING ASSEMBLY

## **CURB FLASHING**

REINFORCED FIELD MEMBRANE **UPTURN FLASHING AT DOOR THRESHOLD**  SCALE: N.T.S. 04-26-2019

999 N. Pacific Coast Highway, Suite 800 PUMADEQ-C3G El Segundo, CA 90245 800-486-1278 • www.henry.com