

## NOTES:

- 1. DETAIL SHOWS HENRY<sup>®</sup> **PUMADEQ<sup>™</sup>** SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEQ™** SYSTEM DETAILS.
- 3. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ**<sup>TM</sup> SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PUMADEQ<sup>TM</sup> SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 4. DO NOT INSTALL **PUMADEQ<sup>TM</sup>** SYSTEM BEYOND PRIMED SURFACES.
- 5. BACK COAT FLEECE ON VERTICAL SUBSTRATE WITH **PUMADEQ™** RESIN.
- 6. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 7. REFER TO **PUMADEQ<sup>TM</sup>** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY $^{\oplus}$  DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

## PUMADEQ<sup>TM</sup> SYSTEM - WATERPROOFING ASSEMBLY

## **CURB FLASHING**

UNREINFORCED FIELD MEMBRANE UPTURN FLASHING AT CURB

SCALE: N.T.S. 04-26-2019

PUMADEQ-C4C

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com