

NOTES:

- DETAIL SHOWS HENRY[®] **PUMADEQ[™]** SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEQ™** SYSTEM DETAILS.
- EXPANSION JOINT MANUFACTURED AND INSTALLED BY OTHERS AS SPECIFIED. CONTACT HENRY® FOR PROJECT SPECIFIC COORDINATION OF $PUMADEQ^{TM}$ SYSTEM WITH EXPANSION JOINT.
- PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ**TM SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PUMADEQTM SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- DO NOT INSTALL **PUMADEQTM** SYSTEM BEYOND PRIMED SURFACES.
- BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ™** RESIN.
- HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY $^{\otimes}$ FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- REFER TO **PUMADEQ™** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQ[™] SYSTEM - WATERPROOFING ASSEMBLY

EXPANSION JOINT

UNREINFORCED FIELD MEMBRANE PREFABRICATED EXPANSION JOINT SCALE: N.T.S. 04-26-2019

PUMADEQ-EJ3

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com