

NOTES:

- DETAIL SHOWS HENRY[®] PUMADEQ[™] SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 150 °F.
- 3. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ[™]** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY[®] **PUMADEQ[™]** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 4. DO NOT INSTALL **PUMADEQ[™]** SYSTEM BEYOND PRIMED SURFACES.
- 5. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ[™]** RESIN.
- 6. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 7. REFER TO **PUMADEQ[™]** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

