

NOTES:

- 1. DETAIL SHOWS HENRY® **PUMADEQTM** SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEQ™** SYSTEM DETAILS.
- 3. FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 150 °F.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ**TM SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PUMADEQTM SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 5. DO NOT INSTALL **PUMADEQTM** SYSTEM BEYOND PRIMED SURFACES.
- 6. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ™** RESIN.
- 7. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 8. REFER TO **PUMADEQTM** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



DUMA DEOTM OVOTEM ANA TERREDOCEINO A COEMPLY

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY 8 DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQTM SYSTEM - WATERPROOFING ASSEMBLY

PIPE PENETRATION

UNREINFORCED FIELD MEMBRANE ON A VERTICAL SUBSTRATE

SCALE: N.T.S.

04-26-2019

PUMADEQ-P2C

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com