

NOTES:

- 1. DETAIL SHOWS HENRY[®] **PUMADEQ[™]** SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEQ™** SYSTEM DETAILS.
- 3. INSTALL MOUNTING COMPONENTS PER MOUNTING PLATE MANUFACTURER REQUIREMENTS. SIZE, PLACEMENT, AND FASTENER HEAD SELECTION AS SPECIFIED. FASTENERS MUST NOT PENETRATE COMPLETELY THROUGH DECK. REMOVE EXCESS THREADS FROM FASTENER AND PEEN INTO PLACE.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQTM** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY[®] **PUMADEQTM** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 5. DO NOT INSTALL **PUMADEQTM** SYSTEM BEYOND PRIMED SURFACES.
- 6. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ™** RESIN.
- 7. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 8. REFER TO **PUMADEQTM** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQTM SYSTEM - WATERPROOFING ASSEMBLY

MOUNTING PLATE

UNREINFORCED FIELD MEMBRANE WITH MOUNTING PLATE INSTALLED DIRECTLY ONTO DECK

SCALE: N.T.S.

04-26-2019

PUMADEQ-P4F

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com