

NOTES:

- DETAIL SHOWS HENRY[®] PUMADEQ[™] SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD
 MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET
 FOR AUTHORIZED SUBSTRATES.
- SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED PUMADEQ™ SYSTEM DETAILS.
- 3. DO NOT INSTALL **PUMADEQTM** SYSTEM OVER SUBSTRATES/AREAS THAT EXCEED MAXIMUM MOISTURE ALLOWANCES. VERIFY DEFICIENCIES DO NOT HAVE PERCOLATING MOISTURE. REFER TO **PUMADEQTM** SYSTEM MOISTURE TEST METHODS TECH-TALK BULLETIN FOR FURTHER INFORMATION.
- 4. REMOVE EXCESS PRIMER FROM DEFICIENCY PRIOR TO APPLYING **PUMADEQTM FLEX 30SL**.
- 5. DO NOT INSTALL **PUMADEQTM** SYSTEM BEYOND PRIMED SURFACES.
- 6. HENRY® OFFERS PAVERS, RIGID INSULATION, AND/OR PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
- 7. REFER TO **PUMADEQTM** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY $^{\oplus}$ DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQ[™] SYSTEM - WATERPROOFING ASSEMBLY

SUBSTRATE DEFICIENCY

UNREINFORCED FIELD MEMBRANE - DEFICIENCIES UP TO 1/2" X 1/2" WITH TOP OR WEAR COAT

SCALE: N.T.S. 04-26-2019

PUMADEQ-SC8

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245

800-486-1278 • www.henry.com