



NOTES:

1. DETAIL SHOWS HENRY VEGETATIVE ROOFING WITH **HENRY 790-11/790-11EV** WATERPROOFING/ROOFING ASSEMBLY. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. PERMANENTLY SECURE DOWEL/REBAR PRIOR TO WATERPROOFING INSTALLATION TO PREVENT VERTICAL OR LATERAL MOVEMENT.
3. DOWEL/REBAR MUST BE FREE FROM RUST, OIL AND CONTAMINANTS.
4. VERIFY WATER OUTLET, SUCH AS DRAINS AND/OR SCUPPERS, ARE LOCATED AT CONFINED SPACES TO AVOID PONDING WATER.
5. DEPTH OF GROWING MEDIA MAY VARY DEPENDING ON PROJECT SPECIFIC REQUIREMENTS.
6. DETAIL IS FOR REFERENCE ONLY. REFER TO DESIGN PROFESSIONAL TO VERIFY WIND UPLIFT MINIMUM REQUIREMENTS.
7. REFER TO THE VEGETATIVE ROOFING GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry[®]

999 N. Pacific Coast Hwy, Suite 800
 El Segundo, CA 90245
 800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

VEGETATIVE ROOFING - HENRY 790-11/790-11EV

**DOWEL/REBAR
 TYPICAL PLANTER DETAIL
 DOWEL OR REBAR PENETRATION**

SCALE: N.T.S.

05/01/2020

VR-790-11-7C