

- 5. DO NOT INSTALL **PUMADEQ** SYSTEM BEYOND PRIMED SURFACES.
- 6. DEPTH OF GROWING MEDIA MAY VARY DEPENDING ON PROJECT SPECIFIC REQUIREMENTS.
- 7. DETAIL IS FOR REFERENCE ONLY. REFER TO DESIGN PROFESSIONAL TO VERIFY WIND UPLIFT REQUIREMENTS.
- 8. REFER TO THE **PUMADEQ** SYSTEM GUIDE SPECIFICATION AND WATERPROOFING DETAILS FOR RECOMMENDED INSTALLATION PROCEDURES.



El Segundo, CA 90245 800-486-1278 • www.henry.com MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

VEGETATIVE ROOFING - PUMADEQ SYSTEM

SUBSTRATE CRACKS REINFORCED FIELD MEMBRANE (CSP 3-5) CRACKS UP TO 1/8" WIDE

SCALE: N.T.S.	06-01-2020
---------------	------------

VR-PUMA-R2