

NOTES:

- DETAIL SHOWS HENRY VEGETATIVE ROOFING WITH PUMADEQ SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- 2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED PUMADEQ SYSTEM DETAILS.
- 3. THIS DETAIL IS INTENDED FOR NON-MOVING SUBSTRATE CRACKS. REFER TO EXPANSOIN JOINT DETAILS FOR AREAS WHERE BUILDING MOVEMENT IS ANTICIPATED.
- 4. DO NOT INSTALL **PUMADEQ** SYSTEM OVER SUBSTRATES/AREAS THAT EXCEED MAXIMUM MOISTURE ALLOWANCES. VERIFY CRACKS DO NOT HAVE PERCOLATING MOISTURE. REFER TO PUMADEQ SYSTEM MOISTURE TEST METHODS TECH-TALK BULLETIN FOR FURTHER INFORMATION.
- 5. REMOVE EXCESS PRIMER FROM CRACK PRIOR TO APPLYING PUMADEQ FLEX 30SL.
- 6. DO NOT INSTALL PUMADEQ SYSTEM BEYOND PRIMED SURFACES.
- 7. DEPTH OF GROWING MEDIA MAY VARY DEPENDING ON PROJECT SPECIFIC REQUIREMENTS.

CRACKS UP TO 1/8" WIDE

- 8. DETAIL IS FOR REFERENCE ONLY. REFER TO DESIGN PROFESSIONAL TO VERIFY WIND UPLIFT REQUIREMENTS.
- 9. REFER TO THE **PUMADEQ** SYSTEM GUIDE SPECIFICATION AND WATERPROOFING DETAILS FOR RECOMMENDED INSTALLATION PROCEDURES.



El Segundo, CA 90245 800-486-1278 • www.henry.com MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

VEGETATIVE ROOFING - PUMADEQ SYSTEM

SUBSTRATE CRACKS UNREINFORCED FIELD MEMBRANE (CSP 3-4)

SCALE: N.T.S.	06-01-2020
---------------	------------

VR-PUMA-U2D