



NOTES:

1. DETAIL SHOWS HENRY VEGETATIVE ROOFING WITH **PUMADEV** SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEV** SYSTEM DETAILS.
3. DO NOT INSTALL **PUMADEV** SYSTEM BEYOND PRIMED SURFACES.
4. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEV** RESIN.
5. PERMANENTLY SECURE DOWL/REBAR PRIOR TO WATERPROOFING INSTALLATION TO PREVENT VERTICAL OR LATERAL MOVEMENT.
6. DOWL/REBAR MUST BE FREE FROM RUST, OIL AND CONTAMINANTS.
7. VERIFY WATER OUTLET, SUCH AS DRAINS AND/OR SCUPPERS, ARE LOCATED AT CONFINED SPACES TO AVOID PONDING WATER.
8. DEPTH OF GROWING MEDIA MAY VARY DEPENDING ON PROJECT SPECIFIC REQUIREMENTS.
9. DETAIL IS FOR REFERENCE ONLY. REFER TO DESIGN PROFESSIONAL TO VERIFY WIND UPLIFT REQUIREMENTS.
10. REFER TO THE **PUMADEV** SYSTEM GUIDE SPECIFICATION AND WATERPROOFING DETAILS FOR RECOMMENDED INSTALLATION PROCEDURES.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

VEGETATIVE ROOFING - PUMADEV SYSTEM

**DOWL/REBAR
UNREINFORCED FIELD MEMBRANE (CSP 3-4)
TYPICAL PLANTER DETAIL**

SCALE: N.T.S. 06-01-2020

VR-PUMA-U7C



999 N. Pacific Coast Hwy, Suite 800
El Segundo, CA 90245
800-486-1278 • www.henry.com