



Notes:

1. Follow appropriate codes for minimum vent height above roof deck.
2. Keep the flashing sheet $\frac{1}{2}$ " back from the vent stack and carry the 790-11 membrane up the stack ensure a complete seal.

Henry
COMPANY

790-11 WATERPROOFING

SCALE: N.T.S.

NOT CAST-IN-PLACE

FIT TO PAPER

**VENT PROJECTION
DETAIL**

WP-H113