

Henry® Pumadeq™ System Adjacent Material Transition Guidelines

Substrate preparation is essential for achieving a successful project and promoting adhesion with adjacent materials. Products listed under transition material in the chart below are intended as supplementary installation instructions, and are in addition to typical product specific requirements. Refer to product specific technical data sheet (TDS), guide specifications and details to verify installation requirements.

The following Henry materials interactions are listed in this document.

1. Air-Bloc® 16MR Fluid Applied Air and Vapor Barrier
2. Air-Bloc 17MR Fluid Applied Vapor Permeable Air Barrier
3. Air-Bloc 33MR Fluid Applied Vapor Permeable Air Barrier
4. Air-Bloc All Weather STPE Fluid Applied Vapor Permeable Air Barrier
5. Blueskin® Adhesive
6. Blueskin Butyl Flash
7. Blueskin SA Self-Adhered Water Resistive Air Barrier
8. Blueskin WP200 Self-Adhered Waterproofing Membrane
9. Blueskin Metal Clad® Self-Adhered Water Resistive Air Barrier
10. Henry 790-11 Hot Applied Rubberized Asphalt
11. Pumadeq System

General substrate conditions

As a requirement for warranty issuance, it is the installing contractor's responsibility to verify substrate conditions are in accordance with Henry published literature. Substrates must be non-aged, clean, dry, free from laitance, ice, snow or frost, dust, dirt, oil, grease, curing compounds or any other foreign matter. Allow products to cure in accordance with product specific TDS prior to subsequent installations.

Adjacent Material Transition Guidelines
n/a - No supplementary transition required

Henry Pumadeq System Adjacent Material Transition Guidelines

Henry Pumadeq System Adjacent Material Transition Guidelines		
Product overlapping adjacent, cured existing Henry product/system	Adjacent, cured existing Henry product/system	Transition material
Pumadeq System	Air-Bloc 16MR	n/a
	Air-Bloc 17MR	n/a
	Air-Bloc 33MR	n/a
	Air-Bloc All Weather STPE	n/a
	Blueskin Butyl Flash	Blueskin Adhesive
	Blueskin SA	Blueskin Adhesive
	Blueskin WP200	Blueskin Adhesive
	Henry 790-11	n/a
	Blueskin Metal Clad	n/a
	Pumadeq System	n/a
Air-Bloc 16MR	Pumadeq System	n/a
Air-Bloc 17MR		n/a
Air-Bloc 33MR		n/a
Air-Bloc All Weather STPE		n/a
Blueskin Butyl Flash		Blueskin Adhesive
Blueskin SA		n/a
Blueskin VP160		Blueskin Adhesive
Blueskin WP200		n/a
Henry 790-11		n/a
Blueskin Metal Clad		n/a
Pumadeq™ System		n/a



Building Envelope Systems®
Roofing | Air Barrier | Waterproofing

Ask us today about other Henry® solutions that help manage the flow of water, air, vapor and energy.