

BLUESKIN WP200
(PRIMER NOT SHOWN FOR CLARITY - SEE DATA SHEET FOR RECOMMENDATIONS)

MECHANICALLY ATTACH PRE-APPLIED WATERPROOFING AND SEAL FASTENER WITH **HENRY 925 BES SEALANT**

HENRY 925 BES SEALANT
(EXTEND 3/4" (20MM) EACH SIDE)

SET PRE-APPLIED WATERPROOFING INTO **HENRY 925 BES SEALANT**
(EXTEND SEALANT 3" (75MM) DOWN VERTICAL SUBSTRATE TO ENSURE PRE-APPLIED WATERPROOFING CONTINUOUS ADHESION WHERE REQUIRED)

HENRY 925 BES SEALANT

BLUESKIN PRESEAL 320
OR **BLUESKIN PRESEAL 435**
(SEE NOTE #2)

HENRY DRAINBOARD
(SEE NOTE #4)

SOIL RETENTION SYSTEM
(DO NOT INSTALL **BLUESKIN PRESEAL 320** DIRECTLY ONTO SHEET PILING - PREPARE SUBSTRATE WITH A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD)

EXTEND PRE-APPLIED WATERPROOFING 12" (300MM) BEYOND ANTICIPATED CONCRETE LEDGE AND TEMPORARILY SECURE UNTIL SUBSTRATE IS IN ACCORDANCE WITH INSTALLATION REQUIREMENTS

6" (150MM)

NOTES:

1. DETAIL SHOWS HENRY PRE-APPLIED WATERPROOFING SYSTEM FOR APPLICATIONS USING HENRY **BLUESKIN PRESEAL 320** OR **BLUESKIN PRESEAL 435**. SUBSTRATE SHOWN IS FOR REFERENCE ONLY.
2. HENRY **BLUESKIN PRESEAL 435** CAN BE INSTALLED DIRECTLY ONTO SHEET PILING. **BLUESKIN PRESEAL 320** REQUIRES A SMOOTH SURFACE SUCH AS PLYWOOD OR DRAINBOARD.
3. APPLICATIONS USING SWELLABLE WATERSTOPS: 3" (75MM) MINIMUM CONCRETE COVERAGE ON ALL SIDES.
4. HENRY RECOMMENDS THE USE OF A DRAINBOARD IN NON-HYDROSTATIC CONDITIONS, OR AS A SUBSTRATE PREPARATION.
5. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET AND GUIDE SPECIFICATION FOR INSTALLATION PROCEDURES.

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

HENRY PRE-APPLIED WATERPROOFING SYSTEM

POST-APPLIED TRANSITION
BLUESKIN PRESEAL 320 OR BLUESKIN PRESEAL 435
TRANSITION WITH BLUESKIN WP200 - GRADE CHANGE

SCALE: N.T.S.

11-06-2023

BSPS-10.B2

