



1. Follow appropriate codes for minimum vent height above roof deck.
2. Set elastomeric flashing sheet in a bed of wet CM100. Allow CM100 to cure.
3. Coat horizontal portion of elastomeric flashing sheet with CM100 and set polyester reinforcement into wet CM100 and allow to cure.
4. Coat polyester reinforcement with CM100 and install protection course.
5. Install stainless steel band clamp and seal with HE925 BES Sealant.

Henry
COMPANY®
www.henry.com

CM100 WATERPROOFING - HIGH BUILD SYSTEM

SCALE: N.T.S.

CAST-IN-PLACE

07-07-09

**PIPE PENETRATION
DETAIL**

CM-HB14