


**PUMADEQ™ SYSTEM WATERPROOFING ASSEMBLY  
UNREINFORCED FIELD MEMBRANE SEQUENCE OF INSTALLATION**


- ① PUMADEQ™ PRIMER 20 OR HENRY® GC PRIMER
- ② PUMADEQ™ FLEX 31MV REINFORCED CORNER FLASHING
- ③ PUMADEQ™ FLEX 31MV REINFORCED CORNER FLASHING (3A AND 3B)
- ④ PUMADEQ™ FLEX 30SL UNREINFORCED FIELD MEMBRANE
- ⑤ OPTIONAL TOP/WEAR COAT AS SPECIFIED PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY REFER TO PUMADEQ™ SYSTEM DETAILS)
  - HENRY® DEQCOAT™ 50 TOP COAT
  - PUMADEQ™ GRIP 40 WEAR COAT

**PUMADEQ™ FLEX 31MV  
REINFORCED FLASHING**





PUMADEQ™ FLEX 31MV  
PUMADEQ™ N-FLEECE


**PUMADEQ™ FLEX 30SL  
UNREINFORCED FIELD MEMBRANE**



PUMADEQ™ FLEX 30SL  
(WHITE)  
PUMADEQ™ FLEX 30SL  
(GRAY)



**PUMADEQ™ N-FLEECE  
CORNER UPTURN FLASHING**



**PUMADEQ™ N-FLEECE  
CORNER FLASHING**

**NOTES:**

1. DETAIL SHOWS HENRY® PUMADEQ™ SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND PUMADEQ™ SYSTEM APPLICATION IN ACCORDANCE WITH HENRY® PUMADEQ™ SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
3. DO NOT INSTALL PUMADEQ™ SYSTEM BEYOND PRIMED SURFACES.
4. BACK COAT FLEECE ON VERTICAL SUBSTRATES WITH PUMADEQ™ RESIN.
5. REFER TO PUMADEQ™ SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

**Henry®**

999 N. Pacific Coast Highway, Suite 800  
El Segundo, CA 90245  
800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

**PUMADEQ™ SYSTEM - WATERPROOFING ASSEMBLY**

**OUTSIDE CORNERS**

**UNREINFORCED FIELD MEMBRANE  
CORNER FLASHING AT UPTURN**

SCALE: N.T.S.

04-26-2019

**PUMADEQ-C1B**