





- (2) PUMADEQ[™] FLEX 31MV REINFORCED FLASHING
- (3) PUMADEQTM FLEX 31MV REINFORCED FLASHING (3A AND 3B)
- (4) PUMADEQTM FLEX 30SL REINFORCED FIELD MEMBRANE
- (5) OPTIONAL TOP/WEAR COAT AS SPECIFIED PER PROJECT SPECIFIC REQUIREMENTS (REFER TO **PUMADEQTM** SYSTEM DETAILS)
 - HENRY® DEQCOAT[™] 50 TOP COAT
 - PUMADEQ[™] GRIP 40 WEAR COAT





TARGET FLASHING TEMPLATE





PUMADEQTM N-FLEECE

FINGER FLASHING TEMPLATE

NOTES:

- DETAIL SHOWS HENRY® **PUMADEQ™** SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
- FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 150 °F. 2.
- PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ**TM SYSTEM APPLICATION IN ACCORDANCE WITH HENRY PUMADEQTM SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN. 3.
- DO NOT INSTALL **PUMADEQ**TM SYSTEM BEYOND PRIMED SURFACES. 4.
- BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ[™]** RESIN. 5.
- REFER TO PUMADEQ™ SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY 8 DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQ[™] SYSTEM - WATERPROOFING ASSEMBLY

PIPE PENETRATION

TOP OR WEAR COAT - HORIZONTAL SUBSTRATES

PUMADEQ-P3A

04-26-2019

SCALE: N.T.S.

REINFORCED FIELD MEMBRANE WITH

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com