

## NOTES:

- DETAIL SHOWS HENRY<sup>®</sup> PUMADEQ<sup>™</sup> SYSTEM WATERPROOFING ASSEMBLY WITH AN UNREINFORCED FIELD
  MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET
  FOR AUTHORIZED SUBSTRATES.
- 2. SURFACE PROFILES MUST MEET ICRI CSP 3-4. IF CSP 5, REFER TO REINFORCED **PUMADEQ™** SYSTEM DETAILS.
- 3. FORM A COOL SLEEVE AROUND PIPES HOTTER THAN 150 °F.
- 4. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ<sup>™</sup>** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY<sup>®</sup> **PUMADEQ<sup>™</sup>** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
- 5. DO NOT INSTALL **PUMADEQ<sup>TM</sup>** SYSTEM BEYOND PRIMED SURFACES.
- 6. BACK COAT FLEECE ON VERTICAL SURFACES WITH **PUMADEQ<sup>™</sup>** RESIN.
- 7. REFER TO PUMADEQ™ SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.



MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

## PUMADEQ<sup>™</sup> SYSTEM - WATERPROOFING ASSEMBLY

## PIPE PENETRATION

UNREINFORCED FIELD MEMBRANE HORIZONTAL SUBSTRATES

SCALE: N.T.S. 04-26-2019

PUMADEQ-P3C

999 N. Pacific Coast Highway, Suite 800 El Segundo, CA 90245 800-486-1278 • www.henry.com