


**PUMADEQ™ SYSTEM WATERPROOFING ASSEMBLY
WITH A REINFORCED FIELD MEMBRANE - SEQUENCE OF INSTALLATION**

- | | |
|--|---|
| <p>① DECK/SUBSTRATE AS SPECIFIED</p> <p>② PUMADEQ™ PRIMER 20 OR HENRY® GC PRIMER</p> <p>③ REINFORCED PUMA FIELD MEMBRANE:
 3A - PUMADEQ™ FLEX 30SL (50 MILS)
 3B - PUMADEQ™ N-FLEECE REINFORCEMENT
 3C - PUMADEQ™ FLEX 30SL (30 MILS)</p> | <p>④ WEAR COAT:
 4A - PUMADEQ™ GRIP 40 (40 MILS)
 4B - DRY SILICA SAND (SEE NOTE #2)</p> <p>⑤ COLOR STABLE TOP COAT:
 5A - HENRY® DEQCOAT™ 50 (20 MILS)
 5B - HENRY® DEQCOAT™ 50 (12 MILS)</p> |
|--|---|



NOTES:

1. DETAIL SHOWS HENRY® **PUMADEQ™** SYSTEM WATERPROOFING ASSEMBLY WITH A REINFORCED FIELD MEMBRANE. SUBSTRATE SHOWN IS FOR REFERENCE ONLY. REFER TO PRODUCT SPECIFIC TECHNICAL DATA SHEET FOR AUTHORIZED SUBSTRATES.
2. FULLY BROADCAST, TO REJECTION, DRY SILICA SAND (SIEVE SIZE: #20-30) INTO WET **PUMADEQ™ GRIP 40**.
3. PREPARE AND PRIME VERTICAL SUBSTRATES A MINIMUM 2" BEYOND **PUMADEQ™** SYSTEM APPLICATION IN ACCORDANCE WITH HENRY® **PUMADEQ™** SYSTEM SUBSTRATE PREPARATION GUIDELINES TECH-TALK BULLETIN.
4. DO NOT INSTALL **PUMADEQ™** SYSTEM BEYOND PRIMED SURFACES.
5. HENRY® OFFERS PAVERS, RIGID INSULATION, AND PREFABRICATED DRAINAGE COMPOSITES AS A SINGLE SOURCE WARRANTY OPTION PER PROJECT SPECIFIC REQUIREMENTS (NOT SHOWN FOR CLARITY). CONTACT HENRY® FOR SYSTEM CONFIGURATIONS AND WARRANTY OPTIONS.
6. REFER TO **PUMADEQ™** SYSTEM GUIDE SPECIFICATION FOR RECOMMENDED INSTALLATION PROCEDURES.

Henry®

999 N. Pacific Coast Highway, Suite 800
 El Segundo, CA 90245
 800-486-1278 • www.henry.com

MANUFACTURER GUIDE DETAILS ARE FOR REFERENCE ONLY. HENRY® DOES NOT ASSUME RESPONSIBILITY FOR ERRORS OR DEVIATIONS IN DESIGN OR ENGINEERING. PROJECT SPECIFIC VERIFICATION IS RECOMMENDED PRIOR TO INSTALLATION.

PUMADEQ™ SYSTEM - WATERPROOFING ASSEMBLY

SYSTEM DETAIL

**REINFORCED FIELD MEMBRANE
 SURFACE PROFILE CSP 3-5 - WEAR AND TOP COAT**

SCALE: N.T.S.

04-26-2019

PUMADEQ-WD